

# WDH14BG

# Hisense



Keep Warm



Touch Control

## General information

Colour of the product: **Black**

## Efficiency

Warming capacity: **Place settings for 6 persons**

Usable volume: **19.8 L**

## Control

Control: **Touch Control**

## Functions

Functions: **Manual temperature setting and timer, Yoghurt, Defrosting of food, Warm preservation, Warming of cups, Warming of plates**

## Features

Air vented circulation: **Yes**

Time setting: **Stop**

Temperature setting: **Yes**

Cold front: **Yes**

Drawer bottom: **Glass**

Removable bottom: **Yes**

## Technical data

Temperature range (°C): **40-80**

Timer range (min): **60-240**

Width of the product: **595 mm**

Height of the product: **140 mm**

Depth of the product: **560 mm**

Width of niche size for installation min.: **564 mm**

Width of niche size for installation max.: **570 mm**

Height of niche size for installation min.: **140 mm**

Depth of niche size for installation min.: **550 mm**

Width of internal space: **460 mm**

Height of internal space: **105 mm**

Depth of internal space: **410 mm**

Width of the packed product: **650 mm**

Height of the packed product: **235 mm**

Depth of the packed product: **670 mm**

Gross weight: **20.1 kg**

Net weight: **18.4 kg**

Voltage: **220 - 230 V**

Frequency: **50 Hz, 60 Hz**

Connected load: **410 W**

Product code: **743456**

EAN code: **3838782768804**

